TOP AND CONSOLE PARTS

27"ELECTRIC DRYER

For Model: 3XLER5437KQ0
(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Model: 3XLER5437KQ0
(Designer White)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	LIT8318458	Label, Wiring Diagram
	LIT8318344	Guide, Use & Care
	LIT8528095	Instructions, Installation

Following May Be Purchased

DO−IT−YOURSELF REPAIR MANUALS

	LIT677818	Manual, Do−It−Yourself Repair (Dryer)
2	8317305	Panel, Rear Console
3	8299770	Timer
4	3347243	Connector, 6−Circuit
5	3395382	Switch, Push−To−Start
6	693995	Screw, 8−18 x 3/8
7	8317342	Cover, Terminal Block
8	8271363	Cap, End (R.H.)
9	8271316	Bracket, Control
10	3390646	Screw, 8−18 x 5/16
12	388326	Screw, Console
13	3399638	Switch, Temperature
14	3391018	Tie, Cable
15	8271339	Knob, Control
16	3397269	Connector, Timer
19	8283161	Harness, Wiring
20	8312687	Timer Knob Assembly
21	8271341	Knob, Push−To−Start
22	8318255	Strap, Console
23	357213	Nut, Push−In (2)
24	8271399	Top
26	8271369	Cap, End (L.H.)
27	3936144	Connector
31	8318383	Panel, Control
32	8283293	Wire, Jumper Assembly
33	3398893	Wire, Ground
35	3390647	Screw, 8−18 x 1/2
36	98139	Screw, 8−32 x 5/16
37	357572	Clip, Grounding
40	8283170	Resistor, Assembly
41	3394427	Clip, Harness
44	94614	Terminal

CABINET PARTS

For Model: 3XLER5437KQ0
(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Model: 3XLER5437KQ0
(Designer White)

Illus. No.	Part No.	DESCRIPTION
2	98139	Screw, 8−32 x 5/16
3	694091	Screw, 8−18 x 3/8
4	3394331	Plate, Cover
5	8318457	Switch, Broken Belt
7	8310656	Cabinet
8	3392100	Foot, Dryer
	279810	Foot − Optional (Extended Length Package Of 2) (Not Included)
9	660658	Clamp, Motor (2)
10	3387374	Spring, Idler
11	3389420	Retainer, Idler
12	697750	Plug, Multivent
13	3388672	Pulley Assembly
14	697776	Screw, 10−32 x 5/8
15	3400934	Screw, 6−20 x 1 1/16
16	340025	Wire, Ground
17	3395532	Exhaust Pipe & Bracket
18	233520	Washer, Thrust
19	3389249	Nut, Inner Door (4)
20	690997	Tri Ring
21	3389247	Hinge & Pin Assembly (2)
22	342055	Screw, 8−18 x 1/2
23	3391408	Lever, Snap Switch
24	3394081	Wire, Belt Switch
25	49026	4" − 90° Elbow
26	3393657	Restrainer, Belt
27	3404470	Motor, Assembly 50 HZ.
28	3395534	Exhaust Pipe (Short)
29	3402548	Pulley 50 HZ.
30	3387610	Belt, Drive
32	3387118	Bracket, Motor
33	3395535	Exhaust Pipe (Long)
34	3388600	Clip, Lint Duct
35	697773	Screw, 6−20 x 7/8
36	693995	Screw, 8−18 x 3/8
37	8318396	Seal, Foam
38	3390902	Clip, Door Hinge (2)
39	3388674	Idler Bracket
40	297092	Clip (2)
41	3406109	Door Switch Assembly
42	3397659	Block, Terminal
43	279318	Terminal, Brass & Tinned (3) Includes Illus. 45
44	3387242	Seal, Front Panel
45	279393	Terminal Block Screw Kit (For Terminal Block)
46	3388229	Retainer
47	3392563	Door, Rear
48	3387258	Cord, Power
49	3387872	Door, Front
50	3393008	Screw, 10−16 x 1/2
51	8317373	Upper Front Panel
52	696144	Strike, Door
56	694415	Clip, Strain Relief
57	3390735	Seal, Door
58	3392538	Catch, Door Assembly
60	3389522	Handle, Door
61	697215	Toe, Panel

Optional Parts Not Included

Dryer Exhaust Kit
(For Side & Bottom Venting)

62	279818	White

OPTIONAL PARTS (NOT INCLUDED)

Illus. No.	Part No.	DESCRIPTION

ACCESSORY PARTS

4392067	Kit, Dryer Repair
3406911	Dry Rack
8522199	Kit, Dryer Vent Testing

PAINT, TOUCH−UP (1/2oz.)

72017	White

PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
350938	Primer, Gray

PAINT, BULK (1 qt.)

799344	White (Uncut)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Model: 3XLER5437KQ0
(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Model: 3XLER5437KQ0
(Designer White)

Illus. No.	Part No.	DESCRIPTION
1	3399508	Shaft, R.H. Thread
2	3390647	Screw, 8−18 x 1/2
3	90767	Screw, 8−18 x 3/8
4	3394986	Spring, Lint Screen Door
5	697354	Air Duct Assembly
6	697813	Seal, Outlet Housing
7	697814	Seal, Drum Front
8	3359452	Nut,3/8 x 16(R.H.)
9	8066086	Drum Hole Plug
10	3390646	Screw, 8−18 x 5/16
11	487909	Screw, 8−15 x 1/2
12	696302	Shield, Exhaust
13	3387230	Screw, 10−16 x 3/4
14	3394984	Door, Lint Screen
15	8318486	Exhaust Pipe
16	3387709	Nut, 3/8−16 (L.H.)
17	3387809	Bulkhead, Rear
18	3387459	Washer, Support
19	3399509	Shaft, L.H. Thread
20	690997	Ring, Tri
21	8536973	Roller, Support
22	8318459	Heater Element
23	3394985	Outlet Housing Assembly
24	697699	Shield, Heat
25	8528998	Complete Drum Assembly
26	97787	Screw, 11−16 x 3/4
27	697694	Seal, Drum
28	697700	Bracket, Heater
29	3390291	Thermostat 250°F (121C)
30	3388229	Clip, Exhaust
31	3977394	Thermal Cut−Off (Includes Illus. 29)
32	8066099	Bracket, Heater
37	697772	Wheel, Blower
42	3387137	Thermostat Internal Bias
44	8530038	Housing, Blower
45	8530036	Lint Duct Assembly
46	3392537	Heater Box
51	3357011	Screw, 10−16 x 1/2
52	697771	Cover, Blower (Includes Illus. 62)
53	8528122	Baffle, Drum
54	697557	Bulkhead, Front
58	8299979	Grill, Outlet
59	3390719	Thermal Fuse
60	697770	Seal, Cover Plate
62	697769	Seal, Lint Duct
64	3390721	Lint, Screen